

## DT-170..

### Installation tester CATEX

#### Application:

The CATEX testers enable you to perform the following checks:

- Presence of voltage at the terminals of a socket.
- Integrity of the earth circuit.
- Correct polarity. The position of the phase and the neutral is indicated.
- Correct operation of the RCD system at the following sensitivities : 30 mA and 500 mA.
- Enables differential circuit breakers to be tested: 10mA/30mA/300mA and 500mA

The RCD check function is only applicable to single phase circuits: 230 V between phase and neutral.

#### Features:

- Operating voltage: 230 V  $\pm$  10%.
- Frequency: 50 / 60 Hz  $\pm$  10%.
- Operating temperature: - 15°C / + 45°C.
- IP 40 IK 03.
- Fuse protection: 2 delayed fuses 250 mA.
- CAT III 600 V

#### Optionnal accessories:

- [M-952271](#) : cord for intervention on LV tables.



Network Type : LV



Référence

**DT-170**

Weight (kg)

0,36